

Dry Transfer Method Vs. Wet Transfer Method:

We suggest installing all graphics using the dry transfer method. Installing it dry will insure that the decal remains adhered to the surface, while wet application may cause the decal to not adhere to the vehicle surface. If installing it wet, NEVER use soapy water. We only support our products when installed dry.

If using the Dry Transfer Method

Step 1 – Make sure that the decal is properly stuck to the transfer tape before installing the decal. Take the squeegee (driver license or credit card) and press firmly over the entire surface of the face of the decal while it is still laying flat on the table.

Step 2 – Clean the surface thoroughly. The cleaner the surface the easier the installation will be.

Step 3 – Align the graphic on desired surface and place a piece of tape on the top of the transfer tape. This will create a hinge for removing the paper backing.

Step 4 – Lift the graphic up and gently pull the paper backing off. This will expose the adhesive graphic. Be sure to pay close attention that the graphic remains on the transfer tape.

Step 5 – Firmly hold graphic by the corners and slowly flip back down so that adhesive is against surface. Once the decal touches the glass or paint, it cannot be moved again!

Step 6 – Use your squeegee (driver license or credit card) and press the graphic firmly. Start from the center and work your way out towards the edges forcing all air out.

Step 7 – Remove the clear transfer tape by pulling straight back. Be sure to pay close attention that the graphic remains on the surface. If graphic comes off with the transfer tape, repeat step 5.

Step 8 – Using your fingers, check all edges of the graphic and confirm they are stuck to the surface. If you have an air bubbles, use a pin and poke a small hole, allowing air to escape. The bubbles may disappear after a day or two.

If Using the Wet Transfer Method

Step 1 – Make sure that the decal is properly stuck to the transfer tape before installing the decal. Take the squeegee (driver license or credit card) and press firmly over the entire surface of the face of the decal while it is still laying flat on the table.

Step 2 – Trim away the transfer tape so that the tape is about (within 1/2") the size as the decal.

Step 3 – Clean the surface thoroughly. The cleaner the surface the easier the installation will be.

Step 4 – Using a spray bottle containing only water, wet the area where decal is to be applied.

Step 5 – Remove the paper backing and place the decal to the thoroughly wetted surface. The decal can now be moved and repositioned correctly; it should slide on a thin layer of water trapped between the vinyl decal and the surface.

Step 6 – When the decal is in the desired location. Use your squeegee (driver license or credit card) and press the graphic firmly. Start from the center and work your way out towards the edges forcing all air out.

Step 7 – Remove the clear transfer tape by pulling straight back. Be sure to pay close attention that the graphic remains on the surface. If graphic comes off with the transfer tape, repeat step 5.

Step 8 – Using your fingers, check all edges of the graphic and confirm they are stuck to the surface. If you have an air bubbles, use a pin and poke a small hole, allowing air to escape. The bubbles may disappear after a day or two.